

# 1-Printer Kurulumu

Öncelikle buradan ip atama programını indirilir. => [Ip Atama Programı](#)

Yazıcı içine pos rulosu konulur ve bilgisayara kutudan çıkan usb kablosu ile bağlanır.

Çalıştırıldıktan sonra uygulamadan sadece new ip değerinin verilip set edilmesi yeterlidir.

Kontrol edilmesi için yazıcı kapatılır sonrasında yazıcıyı açmadan feed tuşuna basılı tutulur ve yazıcı güç düğmesinden yazıcı açılır, basılı tutulan feed butonu bırakılır ve yazıcıdan test sayfası çıkar.

## Ip Atama Programı Görselleri

The screenshot shows the XPrinter V3.0C software interface. The window title is 'XPrinter V3.0C'. The interface is divided into several sections:

- Port Select:** Radio buttons for LPT, COM, USB (selected), and NET.
- Printer Type:** Radio buttons for XP-58, XP-76, and XP-80 (selected).
- LPT Set:** A dropdown menu showing 'LPT1'.
- COM Set:** A dropdown menu showing 'COM1', a text input field with '9600', and a dropdown menu showing 'RTS'.
- NET Set:** A section for configuring network settings. It includes:
  - Local IP:** A text input field with '192 . 168 . 1 . 185' and a 'Refresh' button.
  - Printer IP:** A text input field with '192 . 168 . 2 . 100', a 'Connect' button, and a 'Ping' button.
  - New IP:** A text input field with '192 . 168 . 1 . 100', a 'Set New IP' button, and a 'NetMonitor' button.
  - New ID:** A text input field with '0 . 0 . 0 . 0', a 'New ID' button, and the text '(Set last four ID)'.
- Content:** A section for printer settings. It includes:
  - Rep:** A dropdown menu showing '1'.
  - HEX:** A checkbox that is unchecked.
  - Clear:** A button.
  - AutoSend:** A checkbox that is unchecked.
  - Cyc:** A dropdown menu showing '500 ms'.
  - CutPaper:** A checkbox that is unchecked.
- Printer Control Panel:** A vertical stack of buttons on the right side:
  - Print
  - Cut Paper
  - Open cash drawer
  - Traditional
  - Driver Print
  - Advanced (highlighted with a green box)
- Footer:** The Xprinter logo (芯烨 Xpi) and 'Zhuhai Xprinter Technology' are on the left. '中文简体' is in a button on the right. The website 'www.xprinter.net' and 'Copyright(C) J-SPEED' are at the bottom.
- Status Bar:** A text box at the bottom containing 'Status Bar: Real-time display of print status!'.

Yazıcı bilgisayara bağlandıktan sonra program çalıştırılır ve Advanced butonuna basılır.

Advanced

H Parameter Set: Print H Set Delta 5

Code page Set: PrintCodePage SetCodePage 0

NV Logo Test: NV Download

Barcode Printing test: Print BarCode UPC\_A 129 Height

P76 Buzzer Set: BuzzerSet OFF

P76 Density Set: Set NORMAL

P80 Black sens: Set Sensitivity 12 12 SensH

baud rate set: BaudRate Set 19200 (Only P58 and P76E)

DIP Setting: P58 Set DIP P80 Set DIP P76 Set DIP

2D Barcode test: Print 2D Barcode

Net Setting: Set Net BluetoothSet

USB MODE Setting: USB Printing Virtual COM

Black Mark Setting: BlackMarkSet

File data send: Open File Send

Açılan sayfada Set Net butonuna basılır.

Net Setting

Net Setting

IP Address: 192 . 168 . 10 . 246 SetIPAddr

NetMask 255 . 255 . 255 . 0 SetNetMask

GateWay 192 . 168 . 10 . 1 SetGateWay

Set above contents


WIFI Setting

SSID: TP-LINK\_A1A508

WIFI Key 07563895860 Setting All

Key Type WPA2\_AES\_PSK

Set above contents Return



Son açılan sayfada ise üst kısımda girilecek değerler yazılır ve tamamlandıktan sonra Set above contents butonuna basılır ardından yazıcıdan uyarı sesi gelince işlem tamamlanmış olur.

Revision #7

Created 16 April 2024 17:10:39 by Serhat Türe

Updated 17 April 2024 14:59:48 by Admin